

OPERATIONS AND MAINTENANCE (O&M)


**CRESCENT CITY HARBOR
CALIFORNIA**

SHEET 1 OF 2


SAN FRANCISCO DISTRICT
SOUTH PACIFIC DIVISION

1 JANUARY 2013







CROSS SECTION
STA. 0+00 TO STA. 29+00




CROSS SECTION
STA. 29+00 TO STA. 34+00




TYPICAL DOLOS CROSS SECTION
STA. 34+00 TO STA. 37+00




CROSS SECTION
STA. 37+00 TO STA. 41+20
OUTER BREAKWATER




CROSS SECTION
STA. 41+20 TO STA. 46+70
OUTER BREAKWATER



CROSS SECTION
SECTION A - A
INNER BREAKWATER 400' EXTENSION



CROSS SECTION
SECTION B - B
1200' INNER BREAKWATER



CROSS SECTION
SAND BARRIER

OPERATIONS AND MAINTENANCE (O & M)
**CRESCENT CITY HARBOR
CALIFORNIA**
SHEET 2 OF 2
SAN FRANCISCO DISTRICT
SOUTH PACIFIC DIVISION
1 JANUARY 2013